


Bindapt Adapter Plate Set-up Guide


1. Included in the Box



Bindapt Adapter Plate




Standard Aeration Transition




Ratchet Straps (2)

2. Connecting the Adapter Plates



1. Align the Adapter Plate with the larger diameter side of the Aeration Transition.




2. Slide the Top Fin and Mounting Blocks into the Adapter Plate at a slight angle.




3. Pull the bottom of the Aeration Transition into the Adapter Plate.


3. Secure Plate on Aeration Fan



1. Place assembled Adapter Plate on fan shroud




2. Align Adapter Plate to match fan face




3. Secure Adapter Plate to fan with provided ratchet straps

4. Centrifugal and Inline Orientation

Centrifugal



Inline




NOTE: The Bindapt Adapter Plates will work with all Centrifugal and Inline Aerations fans. The standard Aeration Transition is designed for 3 – 10hp fans. Depending on your fan an additional reducer or larger transition may be required. Please contact Adaptive Agriculture to discuss your fan requirements.

Aeration Transitions


3HP Reducer



10HP Transition



Supercone



Bindapt

✉ info@adaptiveagriculture.ca

☎ 306 - 850 - 1259

🌐 www.adaptiveagriculture.ca